

LINK:
[CONTENT & A-Z](#)



OWNER'S MANUAL.
NAVIGATION, ENTERTAINMENT,
COMMUNICATION.





WELCOME TO MINI.

OWNER'S MANUAL.

NAVIGATION, ENTERTAINMENT, COMMUNICATION.

Thank you for choosing a MINI.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new MINI. Also use the Integrated Owner's Manual in your vehicle. It contains important information on vehicle operation that will help you make full use of the technical features available in your MINI. The manual also contains information designed to enhance operating reliability and road safety, and to contribute to maintaining the value of your MINI.

Any updates made after the editorial deadline can be found in the appendix of the printed Owner's Manual for the vehicle.

Get started now. We wish you driving fun and inspiration with your MINI.

From the MINI Team at BMW AG.

TABLE OF CONTENTS

Navigation, Entertainment and Communication can be called up via the Integrated Owner's Manual in the vehicle.

NAVIGATION

Overview.....	6
Destination input.....	7
Trip.....	12
Map.....	14
Adjusting.....	22
Split screen.....	25
Traffic bulletins.....	27
Navigation data.....	31
Frequently Asked Questions.....	32

ENTERTAINMENT

General information.....	34
Tone.....	36
Radio.....	38
Audio.....	46

COMMUNICATION

Telephone.....	50
MINI Connected.....	61

REFERENCE

Everything from A to Z.....	72
-----------------------------	----

© 2020 Bayerische Motoren Werke
Aktiengesellschaft
Munich, Germany

Reprinting, including excerpts, only with the written consent of BMW AG, Munich.
US English II/20, 03 20 490

Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

Overview

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

The navigation system can determine the precise position of the vehicle with the aid of satellites, and can reliably guide you to every entered destination.

Navigation data is stored in the vehicle and can be updated from a USB storage device.

Calling up the navigation system

1.  Press the button on the Controller.
2.  "Navigation"

Safety information

Warning

Operating the integrated information systems and communication devices while driving can distract from traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or devices when the traffic situation allows. As warranted, stop and use the systems and devices while the vehicle is stationary.

Warning

There can be deviations between the current traffic situation and details of the navigation instructions, for instance changed streets or road construction. There is a risk of accident. The respectively valid traffic rules take precedence.

Destination input

Vehicle features and options



This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

Entering a destination via address

General information

Destination guidance is started to the town/city center if no street is entered.

Selecting the state/province

1.  "Navigation"
2.  "Enter address"
3. "State/Province?"
4. Select the country from the list.

Entering the address

Concept

The address can be entered in any order.

Example: entering the address via the town/city

1. "City/Postal code?"
2. Enter the town/city.

The list is narrowed down further with each entry.

3. **OK** Select the symbol.
4. Move the Controller to the right to select the town/city from the list.
5. If necessary, enter the street.
6. Select the street as you would the town/city.
7. If necessary, enter a house number.
8. **OK** Select the symbol.
9. Select a house number or range of house numbers from the list.

Starting destination guidance



"Start guidance" or Add intermediate destinations, refer to page 12.

Recent destinations



General information


The previous destinations driven to are stored automatically.

Calling up destination from recent destinations

1.  "Navigation"
2.  "Recent destinations"
3. Select the destination.

Deleting the recent destinations

1.  "Navigation"
2.  "Recent destinations"
3. Highlight the destination.

4.  Press the button.
5. "Delete destination" or "Delete all recent destinations"



MINI Cooper SE: last charging stations

General information




The addresses of the 30 last used charging stations, for instance at home are automatically stored.

The charging stations can be called up and used as a destination for destination guidance.

Opening the last charging stations

1.  "Navigation"
2. "Enter new destination"
3.  "Recent charging stations"
4. Select charging station.

Deleting the last charging stations

1.  "Navigation"
2. "Enter new destination"
3.  "Recent charging stations"
4. Highlight charging station.
5.  Press the button.
6. "Delete charging station" or "Delete all charging stations"

Quick search

Concept

Depending on the equipment, Points of Interest and addresses can be searched for by entering a sequence of letters or by search-



ing in the navigation data stored in the vehicle.

All entries are displayed that include this text string.

General information

It is possible to search simultaneously by town/city and street. To do this, enter a text string for the town/city, then a blank space and a text string for the street name.

Calling up quick search

1.  "Navigation"
2. "Enter new destination"
3.  "Quick search"
4. Enter at least three letters or characters.
5. **OK** Select the symbol, if needed.
Results are displayed in a list.
For vehicles with charging socket: charging station display, refer to page 11.
6. Move the Controller to the right.
7. Select desired destination.

Destination entry by voice


General information

- Instructions for the voice activation system, see vehicle Owner's Manual.
- When making a destination entry by voice, you can change between voice operation and operation via Central Information Display (CID).
- To have the available voice commands read out loud: >Voice commands< or >Help<.

Saying the entries

- Complete addresses can be spoken as a single command, or countries, towns/cities, streets and intersections can be spoken as whole words. The language of the system must be set to the language of the destination country.
- Addresses can be spelled, even when the configured language of the system is different.
Say the letters smoothly, and avoid exaggerating the pronunciation and inserting lengthy pauses between the letters.
- You can search for points of interest for the navigation online in natural language, such as with a question for specific restaurants nearby.
- The options available for entering data depend on the navigation data and the country and language settings.

Entering an address in a command

1.  Press the button on the steering wheel.
2. >Enter destination<
3. Wait for a request from the voice activation system.
4. Say the address in the suggested order.
5. Continue making the entry as prompted by the voice activation system.



If necessary, individually name the separate parts of the address, for instance the town/city.

Home address



General information

The home address must be stored.

Using the home address as the destination

1.  "Navigation"
2. "Enter new destination"
3.  "Home address"

Defining the home address

1.  "Navigation"
2. "Enter new destination"
3.  "Set home address"
4. Enter the address and possibly a name and further details.

Changing the home address

The home address is stored in the contacts and can be changed there. Edit contacts, refer to page 53.



Charging stations and Points of Interest

General information

Points of Interest are destinations that can be helpful while driving. Points of Interest such as restaurants, hotels, gas stations, or charging stations, can be added as destinations. Even with the most current navigation data, information regarding particular Points of Interest may have changed. For instance, certain gas stations may not be operating.

Find Points of Interest

Calling up Points of Interest

1.  "Navigation"
2. "Enter new destination"
3.  "Points of Interest"
4. Select the desired setting:

- "Keyword search" or "Category search": search for Points of Interest in the navigation data stored in the vehicle.
- Search via preferred Points of Interest categories.

Keyword search

1. "Keyword search"
2. Enter a search term.
3. **OK** Select the symbol.
Points of Interest at the current location are searched for.
A list of the Points of Interest is displayed.
The Points of Interest are sorted by distance.
For vehicles with charging socket: charging station display, refer to page 11.
4. "Change location and sorting": the search can be adjusted, if needed.
 - "Location": change search location.
 - "Sort by": change sorting.
5. Select a Points of Interest.
Details are displayed.
6. Select the address.
7. If necessary, "Start guidance"

Category search

1. "Category search"
2. "All categories" or select the desired Points of Interest category.
Points of Interest at the current location are searched for.
3. A list of the Points of Interest is displayed.
The Points of Interest are sorted by distance.

For vehicles with charging socket: charging station display, refer to page 11.

4. "Change location and filter criteria": adjust the search criteria if needed:
 - "Location": change search location.
 - "Sort by": change sorting.
 - If necessary, select category details.
 - "Keyword": narrow down the list via a keyword search.
5. "Show results"
6. Select a Points of Interest.
Details are displayed.
7. Select the address.
8. If necessary, "Start guidance"

Preferred Points of Interest categories

The Points of Interest categories that have been search for the most are displayed.


Select a preferred Points of Interest category to search for Points of Interest in the desired category at you current location.

Displaying Points of Interest on the map

Concept

The Points of Interest categories can be displayed on the map as symbols.

Selecting categories




1.  "Navigation"
2. "Settings"
3. "Map elements"
4. "Points of Interest"
5. Select the desired setting.

The display in the function bar of the map view, refer to page 20, can be switched on and off.



For vehicles with charging socket: charging station display

General information

Depending on the equipment, different symbols indicate charging stations in the map view:

-  AC charging stations.
-  DC charging stations, where AC charging may also be possible.
-  ChargeNow charging stations, can be used with the ChargeNow card or possibly the ChargeNow app.

Selecting a destination from the contacts

1.  "Navigation"
2. "Enter new destination"
3.  "Contacts"

Contacts with addresses are displayed if these have been checked as destinations from among the Contacts. Check the address as a destination, refer to page 53.

4. Select a contact.
5. Select the address.
6. "Start guidance"

Destination entry using GPS coordinates



Concept

Destinations can be entered directly using GPS coordinates.

General information

Enter the coordinates in degrees, minutes and seconds or as decimal values.

Opening



1.  "Navigation"
2. "Enter new destination"
3.  "GPS coordinates"
4. "Format"
 - "Degrees Minutes Seconds"
 - "Decimal"
5. "Longitude" or "Latitude"
6. Turn the Controller until the desired degree indication and point of the compass are displayed.
7. Press the Controller.
8. Enter the values for minutes and seconds and direction, if needed.
9. "Accept destination"

Destination entry via Concierge service

General information

Concierge service provides information, for instance about hotels and restaurants. Addresses can be transmitted directly to the navigation system.

Calling up the Concierge service

1.  "Navigation"
 2. "Enter new destination"
 3.  "Concierge"
- A voice connection to the Concierge service is established.

Trip




Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

When planning a trip, several intermediate destinations can be entered.

New trip

1.  "Navigation"
2. "Map"
3. Move the Controller to the left, if needed.
4.  "Guidance"
5. "Enter new destination"
6. Select the type of destination entry.
7. Select a single destination.
8. Enter an intermediate destination.
9.  "Start guidance"


Intermediate destinations

General information



Before entering an intermediate destination, an individual destination must be set.

A maximum of 30 intermediate destinations can be entered for one trip.

Entering an intermediate destination



1.  "Navigation"
2. "Add intermediate destination"
3. Select the type of destination entry.
4. Enter an intermediate destination.

Alternatively, the intermediate destination can also be entered using the map:

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Guidance"
5. "Add intermediate destination"
6. Select the type of destination entry.
7. Enter an intermediate destination.

The intermediate destination is entered in the destination list and is highlighted.

Adjusting the intermediate destinations

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Guidance"
5. Select the intermediate destination.
6. Select the desired setting:


- "Skip destination": skip the current intermediate destination.
- "Start guidance": start destination guidance to the intermediate destination.
- "Change order": move the intermediate destination within the list.
- "Delete destination": delete the intermediate destination.


Map

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

Opening the map

1.  "Navigation"
2. "Map"

 The map can also be accessed directly with the button on the Controller.


Overview

General information

The map can be used via the Central Information Display (CID).





Basic entry explanation, refer to the Owner's Manual for the vehicle.





Map view



- 1 Function bar
- 2 Route section with traffic obstruction
- 3 Traffic sign for traffic obstruction
- 4 Planned route
- 5 Current location
- 6 Status field
- 7 If equipped with touchscreen: display current location

Function bar

Symbol	Function
	Start/end destination guidance. MINI Cooper SE: when the symbol is yellow or red, the range is hardly sufficient or insufficient. Range assistant, refer to page 15.
	Change current route.
	Switch spoken instructions on and off.
	Traffic bulletins. Status of the traffic bulletins.

Symbol	Function
	Detour available.
	Display additional information on map.
	Select the map view.
	Interactive map.

To change to the function bar, move the Controller to the left.

Status field

The following information is displayed:

- Symbol for active destination guidance.
- Time of arrival and distance to destination.
- If necessary, time delay due to traffic obstructions.

Lines in the map

Streets and routes are displayed in different colors and line styles depending on their classification.


- Dashed lines: railways and ferry connections
- Thin lines: country borders.

Traffic obstructions

If traffic bulletins of a radio station or a traffic information service are received, traffic obstructions can be displayed on the map.

Destination guidance



Starting

1.  "Navigation"
2. Enter the destination, refer to page 7.

3.  "Start guidance"

After the route has been started, a message is displayed with the most important set route criteria.

Exit

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  Select the symbol.
5. "Stop guidance"

MINI Cooper SE: Range Assistant

Concept

A check is made of whether an entered destination can be reached with the current charging state of the vehicle.

General information

The range to a charging station that has already been used, such as home, can be monitored, refer to page 23.

Range recommendations

General information

If the electrical range is not sufficient, various recommendations to help increase the range are displayed automatically.

- "Mode and route: GREEN +": apply efficient route.
- "Mode: GREEN +": switch to GREEN +.
- "Charging station search": search for charging stations along the route or in the vicinity, if applicable.

GREEN Route

An efficient variant of the route can be calculated and applied in the destination guidance. The new route is displayed in the map

view and continued in the destination guidance. Time of arrival and consumption are based on driving in GREEN.

1. "Mode and route: GREEN +"

GREEN +

The range can be increased by switching to GREEN +.


1. "Mode: GREEN +"
2. Activate GREEN + with MINI Driving Modes switch.



Search charging stations

Charging stations along the route are searched and can be applied as destinations in the destination guidance or as intermediate destinations.

1. "Charging station search"
2. Select desired charging station.

Manually displaying range recommendations

 When the symbol in the map function bar is yellow or red, the recommendations for increasing the range can be displayed manually.




1.  "Navigation"
2. "Map"
3. Move the Controller to the left, if needed.
4.  "Guidance"
5. "Range insufficient."

Storing the current destination as contact

Concept

After entering the destination, it can be stored in the contacts.

Storing

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Guidance"
5. Select the destination.
6.  Press the button.
7. "Save as new contact" or "Add to contact"
8. Select an existing contact, if available.
9. Enter name and, if necessary, additional details.
10. "Save contact in the vehicle"

Changing the route details

Route criteria

General information


The route calculated can be influenced by selecting certain criteria. The recommended route may differ from the route you would take based on personal experience.





Standard settings for route criteria

The route criteria can be individually adjusted. The settings are stored as standard and automatically applied to new destination guidances.

Default settings for route, refer to page 22.

With destination guidance active: changing route criteria in the map view

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.






4.     "Route"
5. Select the desired setting.
6. If necessary, select general routine criteria: "General route settings"

Alternative routes

Concept

If possible, alternative routes are suggested during active destination guidance.

Displaying alternative routes

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
An overview showing the current route and the suggested alternative routes is displayed. In addition, details such as travel time and route length, and information about consumption for the alternative routes compared to the current route may be displayed, if required.
The routes are shown in color on the split screen.
5. Select an alternative route in order to apply it to the destination guidance.

Route details

Concept

During destination guidance, more detailed information about the current route can be displayed and the route can be adjusted.

General information

Depending on the equipment, different views of the route are available during destination guidance:

- List of route sections, refer to page 17.
- Map view, refer to page 14.

- Destination guidance notes on the map, refer to page 20.
- Arrow view in the split screen, refer to page 25.
- Arrow view in the instrument cluster.

List of route sections






Concept

When destination guidance is activated, a list of route sections can be displayed.

General information

The distance to be driven per route section is displayed. If needed, gas station or charging recommendations are displayed as well.

Displays







1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
5. "Route details"
6. Highlight route section.
The route section is displayed on the split screen.

Bypassing a section of the route

Concept







A new route can be calculated for a route section.

Setting a detour

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
5.  "Change route"
6. "Detour:"

7. Turn Controller until the desired distance before returning to the original route is displayed.
8. Press the Controller.

Resuming the original route

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
5.  "Change route"
6. "Delete detour"

Vehicles with combustion engine: gas station recommendation

Concept







The remaining range is calculated, and if needed, gas stations along the route are displayed.

General information


Even with the most current navigation data, information regarding individual gas stations may have changed. For instance, certain gas stations may not be operating.

Gas station recommendations are displayed in the Route list, refer to page 17.

Opening

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
5. "Route details"
6.  "Refuel"
A list of gas stations is displayed.
7. Highlight a gas station.

The location of the gas station is displayed on the split screen.

8. Select the gas station.
9.  Select the symbol.
10. "Start guidance"

MINI Cooper SE: charging recommendation

Concept








When destination guidance is active, the remaining range is calculated and, if needed, charging stations along the route are displayed.

General information

Even with the most current navigation data, information regarding individual charging stations may have changed. For instance, certain charging stations may not be operating.

Charging recommendations are displayed in the route list, refer to page 17.

Opening







1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.    
5. "Route details"
6.  "Charging"
A list of the charging stations is displayed.
7. Highlight charging station.
The location of the charging station is displayed on the split screen.
8. Select charging station.
9.  Select the symbol.
10. "Start guidance"

Changing the route details







Concept

With active destination guidance, the route displayed on the map can be adjusted manually. To do this, use a marking point on the route, the 'route magnet,' to drag the route in the desired direction.

Setting a route magnet

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
5.  "Change route"
6. "Add route magnet"
7. As with the interactive map, drag route magnet to the desired location using the Controller:
 - To change the scale: turn the Controller.
 - To shift the map: move the Controller in the required direction.
 - To shift the map diagonally: move the Controller in the required direction and turn it.
8. Press the Controller.
9. "Accept magnet"

Editing a route magnet




1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.     "Route"
5.  "Change route"
6. Select the desired setting:
 - "Modify route magnet": modify changed route once more.

- "Remove route magnet": the original route is restored.


Spoken instructions

Switching on/off

The setting is stored for the driver profile currently used.

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.   "Voice instructions"

Repeat

1.  "Navigation"
2. "Map"
3. Press the Controller.
4. "Repeat voice instruction"

Using the button:



Press the button twice.








Volume

Turn the volume button during the spoken instructions until the desired volume is set.

Storing on the programmable memory buttons

The function for switching the spoken instructions on/off can be stored on a programmable memory button for quick access.

Displaying additional information on the map

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Map content"
5. Select the desired setting:
 -  "Points of Interest": symbols for Points of Interest are displayed.
 -  "Traffic flow": lines for traffic flow are displayed.
Information about traffic flow in the map view, refer to page 29.
 -  "Traffic icons": symbols for traffic bulletins are displayed.
 -  "Weather": display weather symbols on the map.
 - MINI Cooper SE:
 -  "Electric range (2D)": the ranges with the current and most economical program of the MINI Driving Modes switch based on the GREEN Route are displayed as colored lines on the map. If a preferred charging station has been specified, it is also displayed on the map. Specifying a preferred charging station, refer to page 23.

Map view

Concept










The map view can be displayed in different perspectives, such as north-oriented or facing the direction of travel.

General information

The scale of the map can be enlarged or reduced.

Additional settings for map, refer to page 23.

Selecting a map view

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Map views"
5. Select the desired setting:
 -  "Facing north"
 -  "Direction of travel"
 -  "Perspective"
 -  "Auto zoom": with active destination guidance, the map is enlarged automatically when approaching a maneuver.
 -  "Auto zoom with info": with active destination guidance, the map is enlarged automatically when approaching a maneuver. In addition, destination guidance hints are displayed on the map.
 -  "Manual zoom": enlarge or reduce map scale manually.
 -  "Route overview": display the route between current location and the destination.

Destination guidance hints

Concept

If destination guidance is active, destination guidance hints can be displayed in the map view for the respective maneuvering points of the current route.

General information

In the case of multi-lane roads, lane information may indicate the recommended lanes.

Destination guidance hints can also be displayed as arrow view in the split screen, refer to page 25.

Display



Functions in the map view

General information

Different information can be called up for any point on the map and settings can be adjusted.

Here, the map can be used via the Central Information Display (CID).

Operating via the Controller

1. "Navigation"
2. "Map"
3. Move the Controller to the left.
4. "Interactive map"
5. Select the destination with crosshairs.
 - To change the scale: turn the Controller.
 - To shift the map: move the Controller in the required direction.

- To shift the map diagonally: move the Controller in the required direction and turn it.

6. Press the Controller.
7. Select the desired setting.

Functions

Different functions are available depending on the point selected on the map:

- "Repeat voice instruction"
With destination guidance active.
- "Start guidance": start destination guidance.
- "Add as intermediate dest.": add destination.
- "Show details": details about the destination can be displayed as necessary.
- "Show details": if the crosshairs are positioned over a place with multiple Points of Interest, these destinations will be displayed in a list.
- "Leave interactive map": with operation via Controller: end interactive map.
- If equipped with touchscreen:
 - "Back to current location": change to normal map view.
 - "Show destination": map section around the destination is displayed.
 - "Save position": store current position as contact.
 - "Change map view": change the map view.

Adjusting

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information


Navigation settings can be individually configured. Settings are stored for the driver profile currently used.

Route

Concept


The route criteria can be individually adjusted. The settings are stored as standard and automatically applied to new destination guidances.

Default preference

1.  "Navigation"
2. "Settings"
3. "Route settings"
4. "Default preference"
5. Select the desired setting:
 - "Fast": time-optimized route, being a combination of the shortest possible route and the fastest roads.

- "Short": distance-optimized route, being a combination of the shortest possible route and the fastest roads.
- "GREEN" or "Efficient": efficient route, being a combination of the route requiring low consumption and fast roads.
Time of arrival and consumption are based on driving in GREEN Mode.

Further criteria


1.  "Navigation"
2. "Settings"
3. "Route settings"
4. Select the desired setting:
 - Settings for dynamic destination guidance:
 - "Automatic": traffic bulletins are considered in destination guidance. The current route is automatically changed as needed.
 - "With confirmation": when suitable detours are available, a message is displayed first.
 - "Toll roads"
 - "Avoid"
 - "Use cash"
 - "Toll tag"
 - "Avoid highways": highways are avoided wherever possible.
 - "Avoid ferries": ferries are avoided where possible.
 - "Avoid carpool roads": carpool lanes are avoided where possible.

Map

Concept

The map view can be individually adjusted, for instance the map color and mode can be set. It can also be defined, which Points of Interest are shown on the map.

Setting the map


1.  "Navigation"
2. "Settings"
3. Select the desired setting.

Home address

Concept

The home address can be specified or changed.

Setting the home address

1.  "Navigation"
2. "Settings"
3. "Set home address" or "Change home address"

MINI Cooper SE: checking charging stations

Concept


The range to a charging station that has already been used, such as home, can be monitored. For this purpose, the respective charging station must be set as a preferred charging station.

General information

When destination guidance is activated, the range to the destination and to the specified





charging station is monitored. First, the range to the destination is monitored and recommendations for increasing the range are displayed if applicable. The range to the specified charging station is then checked.

Specifying a preferred charging station

1.  "Navigation"
2. "Settings"
3. "Range monitoring"
4. "Set preferred charging station"
5. Select desired charging station.


Display

The preferred charging station is displayed together with the range on the range map, refer to page 20.


Color	Meaning
 Green	Charging station within range.
 Yellow	Charging station just within range.
 Red	Charging station not within range.
 White	Route not yet calculated.

Activate/deactivate charging station checking

Range monitoring can only be activated or deactivated when a preferred charging station has been set.

1.  "Navigation"
2. "Settings"
3. "Range monitoring"
4. "Monitoring"

Deleting a preferred charging station


1.  "Navigation"
2. "Settings"
3. "Range monitoring"
4. "Remove preferred charging station"

Navigation data



Concept

Information regarding position determination and navigation data version can be called up.

Adjusting

1.  "Navigation"
2. "Settings"
3. "Position and software version"
4. Select the desired setting:
 - "Enter position": the vehicle position can be manually set on the map in situations without GPS reception or, for instance immediately after transport on a ferry.
 - "Software version": information about the current map version.

Resetting the settings

1.  "Navigation"
2. "Settings"
3.  Press the button.
4. "Reset all settings"

Split screen

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

Concept

When equipped accordingly, additional information can be displayed in several menus on the right side of the split screen display, referred to as the split screen. Different views can be set for the split screen separately from the main screen.

Adjusting

1. Move the Controller to the right until the split screen is selected.
2. Press the Controller.
3. Select the desired setting:
 - "Map": set the map view.
 - "Map view.": select the map view.
 - "Traffic flow": display the traffic flow.
 - "Traffic icons": display traffic events.
 - "Route overview": display the route overview.

- "Arrow display": with destination guidance active, the arrow view is displayed. A compass is displayed when the destination guidance is inactive.
- "Position": display current position.
- "Exit ramp view": selected route sections, for instance major road intersections, are shown in perspective view.

Arrow view

Concept

If destination guidance is active, the destination guidance hints can be displayed as list in the split screen.

General information

It is possible to set which additional information should be displayed in the arrow view.

In the case of multi-lane roads, lane information may indicate the recommended lanes.

Adjusting

1. Move the Controller to the right until the split screen is selected.
2. Press the Controller.
3. "Arrow display"
4. Select the desired setting:
 - "Traffic Info": display traffic flow and traffic events.
 - "Additional information": display additional information such as tunnels.

Display

The following information is displayed during destination guidance:



- 1 Turn information
- 2 Traffic flow and traffic events
- 3 Upcoming street
- 4 Distance to maneuver
- 5 Lane information
- 6 Current road

Depending on the country-specific version, the display may deviate from what is depicted.

Traffic bulletins

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

Traffic bulletins from traffic warning services or radio stations that broadcast Traffic Information TI can be displayed in the map view and taken into account when calculating routes. Information on traffic obstructions and hazards is updated continuously in this system.

The traffic bulletins are indicated on the map by symbols.

In the event of special hazards, for instance objects on the road, a message is displayed. Several hazard messages are also displayed in the instrument cluster as a Check Control message.

Certain MINI models equipped with navigation have the capability to display traffic information. If your system has this capability, the following additional terms and conditions apply:

An End-User shall no longer have the right to use the traffic information in the event that the End-User is in material breach of the terms and conditions contained herein.

MINI or its third party providers hold the rights to the traffic data. You may not modify, copy, scan or use any other method to reproduce, duplicate, republish, transmit or distribute in any way any portion of traffic data.





The traffic data is for informational purpose only. Users assume all risk of use. MINI NA and its service providers make no representations about content, traffic and road conditions, route usability, or speed.

THE TRAFFIC DATA IS PROVIDED TO YOU "AS IS," AND "WHERE IS". MINI NA AND ALL THIRD PARTY PROVIDERS OF ANY OF THE TRAFFIC DATA, EXPRESSLY DISCLAIMS, TO THE FULLEST EXTENT PERMITTED BY LAW, ALL EXPRESS, IMPLIED OR STATUTORY WARRANTIES OR REPRESENTATIONS WITH RESPECT TO THE TRAFFIC DATA (INCLUDING, WITHOUT LIMITATION, THAT THE TRAFFIC DATA WILL BE ERROR-FREE, WILL OPERATE WITHOUT INTERRUPTION OR THAT THE TRAFFIC DATA WILL BE ACCURATE), INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT FITNESS FOR A PARTICULAR PURPOSE, OR THOSE ARISING FROM A COURSE OF DEALING OR USAGE OF TRADE

NEITHER MINI NA NOR ITS THIRD PARTY PROVIDERS WILL BE LIABLE TO YOU FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL, EXEMPLARY, OR INCIDENTAL DAMAGES (INCLUDING, WITHOUT LIMITATION, LOST REVENUES, ANTICIPATED REVENUES, OR PROFITS RELATING TO THE SAME) ARISING FROM ANY CLAIM RELATING DIRECTLY OR INDIRECTLY TO USE OF THE TRAFFIC DATA, AND EVEN IF MINI NA OR ITS THIRD PARTY PRO-

VIDERS ARE AWARE OF THE POSSIBILITY OF SUCH DAMAGES. THESE LIMITATIONS APPLY TO ALL CLAIMS, INCLUDING, WITHOUT LIMITATION, CLAIMS IN CONTRACT AND TORT (SUCH AS NEGLIGENCE, PRODUCT LIABILITY AND STRICT LIABILITY). SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THOSE PARTICULAR LIMITATIONS MAY NOT APPLY TO YOU.

Display in the function bar of the map view

Sym- bol	Function
	Yellow symbol: The traffic bulletins relate to the calculated route and the anticipated delay is less than 20 minutes.
	Red symbol: The anticipated delay is more than 20 minutes, or there is a road block or hazard warning for the route.
	Gray symbol: No traffic bulletins are available or the anticipated delay is less than 5 minutes.
	A suitable detour is available for the traffic bulletins.

Real Time Traffic Information RTTI

In some countries, RTTI is transmitted.


RTTI is then used and displayed instead of the traffic bulletins from the radio stations.

With RTTI, traffic obstructions are localized more comprehensively and precisely. Traffic conditions on roads other than the highways, for instance secondary roads and urban streets are also recorded and displayed for a wide area. Recommended detours can be calculated more accurately on the basis of this information. The risk of becoming caught in a further traffic obstruction on detour routes is reduced. If applicable, several detour recommendations or additional information may be offered.




When traveling in countries where RTTI is not available, the traffic bulletins from the radio stations are still used, if possible.

The function bar in the map view, refer to page 14, shows whether Traffic Information TI or RTTI is being used.

Switching on/off

1.  "Navigation"
2. "Settings"
3. "Receive Traffic Info"

Displaying list of traffic bulletins



1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.   "Traffic Info"

With active destination guidance, first the traffic bulletins for the calculated route are displayed with red symbols. Then, the traffic bulletins that do not affect the route are shown with gray sym-

bols. The traffic bulletins are sorted by their distance from the current position of the vehicle.

5. Select a traffic bulletin.
 - "Previous message": scroll to the previous traffic bulletin.
 - "Next message": scroll to the next traffic bulletin.

Displaying detour recommendation





1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Traffic Info"
5. "Detour": a detour recommendation is displayed.

The following functions are available:

- "Current route": stay on current route.
- "New route in": accept detour.

Traffic bulletins on the map

Map view settings

1.  "Navigation"
2. "Map"
3. Move the Controller to the left.
4.  "Map content"
 -  "Traffic icons": symbols for traffic events are displayed.
 -  "Traffic flow": lines for traffic flow are displayed.

Symbols in the map view

Depending on the scale of the map and the location of the traffic obstruction, the symbols for traffic events are displayed.

Information about traffic flow in the map view

Depending on the scale of the map, length and impact of a traffic obstruction are displayed on the map using colored lines.

- Black: road blocked.
- Red: congestion.
- Orange: stop-and-go traffic.
- Yellow: heavy traffic.
- Green: clear roads.
- Gray: general traffic bulletins, for instance construction site.


The displayed information depends on the particular traffic information service.

Dynamic destination guidance

Concept

With dynamic destination guidance, traffic bulletins are considered when calculating routes.

Adjusting

1.  "Navigation"
2. "Settings"
3. "Route settings"
4. "Dynamic guidance"
5. Select the desired setting:
 - "With confirmation": a message is displayed, whether the route should be guided around a traffic obstruction.

- "Automatic": the route is automatically changed in the event of traffic obstructions.

Navigation data


Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

Concept

Information regarding position determination and navigation data version can be called up.

Adjusting

1.  "Navigation"
2. "Settings"
3. "Position and software version"
4. Select the desired setting:
 - "Enter position": the vehicle position can be manually set on the map in situations without GPS reception or, for instance immediately after transport on a ferry.
 - "Software version": information about the current map version.

Map update

General information

Navigation data is stored in the vehicle and can be updated from a USB storage device.

Up-to-date navigation data is available from a dealer's service center or another qualified service center or repair shop.


Depending on the data volume, the navigation data update may take several hours. The status of the update can be queried.

The navigation data is updated during the trip to preserve the vehicle battery.

Update

1. Connect the USB storage device with the new navigation data at a USB port in the front.
2. Follow the instructions on the Control Display.
3. Remove the USB storage device after the update.

Viewing the status

1.  Press the button.
2. "Saving navigation data in the vehicle... (USB)"

Automatic map update

General information

Depending on the vehicle equipment and country version, the navigation data for the home region is transmitted online to the vehicle four times a year and automatically installed and updated.

Frequently Asked Questions

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems.

When using these functions and systems, the applicable laws and regulations must be observed.

- The destination data is not contained in the navigation data. Select a destination that is as close as possible to the original.

Why are spoken destination guidance instructions not provided at intersections?

- You have left the recommended route and the system requires a few seconds to calculate a new route suggestion.

Frequently Asked Questions

Why can the current position not be displayed?

- The vehicle is located in an unrecognized region, is in a poor reception area, or the system is currently determining the position.

Reception is usually best when you have an unobstructed view of the sky.

Why does destination guidance not accept a destination without the street?

- No downtown can be determined for the entered town/city.

Input any street in the selected town/city and start destination guidance.

Why does destination guidance not accept a destination?

- The destination data is not contained in the navigation data. Select a destination that is as close as possible to the original.

Why can letters not be selected for destination input?

General information

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

Control elements



- 1 Waveband/satellite radio
- 2 Change entertainment sources
- 3 Sound output on/off, volume
- 4 Changing the station/track
- 5 Programmable memory buttons

Sound output

Safety information

Warning

A high sound output volume can damage your hearing. There is a risk of injury. Do not adjust the volume too high.

Volume and sound output



- Turn the button to adjust the volume.
- Press the button to switch off the sound output. Pressing the button again restores the previous volume setting.

Audio recording playback is stopped during muting.

Entertainment sources

General information

Possible entertainment sources:


- Radio, refer to page 38.
- USB audio, refer to page 46.
- Bluetooth audio, refer to page 47.
- Apple CarPlay, refer to page 66.

Changing the entertainment source


On the radio:

1.  Press the button.



A list of all currently available entertainment sources is displayed.

2.  Press the button again to select an entertainment source.

Via the Central Information Display (CID):

1.  "Media/Radio"
A list of all possible entertainment sources is displayed.
2. Select the desired entertainment source.

Via the button on the Controller:

1.  Press the button.
The most recently selected entertainment source is played.
2.  Press the button again.
A list of all currently available entertainment sources is displayed.
3. Select the desired entertainment source.

Tone


Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

Settings are stored for the driver profile currently used.

Treble, bass, balance, and fader


1.  "Media/Radio"
2. "Tone"
3. Select the desired setting:
 - "Treble": treble adjustment.
 - "Bass": depth adjustment.
 - "Balance": left/right volume distribution.
 - "Fader": front/rear volume distribution.
4. To adjust: turn the Controller.
5. To store: press the Controller.

Volume equalization

Concept

An automatic increase of the volume can be set to compensate for the increasing driving noises at higher speeds.

Set automatic volume increase

1.  "Media/Radio"
2. "Tone"
3. "Volume settings"
4. Select the desired setting:
 - "Navigation": ratio of spoken instructions volume to entertainment volume.
 - "Speed volume": ratio of entertainment volume to speed.
 - "PDC": ratio of the volume of the PDC signal tone to the entertainment volume.

The basic setting ensures that the signal tone is audible at any volume.

- "Gong": ratio of the volume of the signal tone, for instance for safety belt reminder, to the entertainment volume.
- The basic setting ensures that the signal tone is audible at any volume.
- "Microphone": sensitivity of the microphone during a phone call.
- The setting is adjusted while calling and is stored for the mobile phone used.
- "Speakers": volume of the loudspeakers during a phone call.

Audio recording playback is stopped during muting.

The setting is adjusted while calling and is stored for the mobile phone used.

5. To adjust: turn the Controller.
6. To store: press the Controller.

Reset the tone settings

The tone settings are reset to the factory settings.

1. 🎵 "Media/Radio"
2. "Tone"
3. "Reset"

Radio

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

Settings are stored for the driver profile currently used.

AM/FM station

General information

Depending on the vehicle equipment and country version, it may not be possible to receive AM stations.

Radio Data System RDS

Concept

RDS broadcasts additional information, such as the station name, in the FM waveband.


It is recommended to switch on RDS.

Switching on/off

1.  "Media/Radio"
2. "FM"

3.  Press the button.
4. "RDS"

Selecting a station

1.  "Media/Radio"
2. "FM" or "AM"
The last station listened to will be played and the station list displayed.
3. Select the desired station.

Changing the station

On the radio:



-  Press the left or right button.

The previous or next station from the list of stations is played.



Storing a station

General information


A symbol on the highlighted channel indicates whether the channel has already been stored.

Symbol	Meaning
	Station is not stored.
	Station is already stored.

Storing the station being played

1.  "Media/Radio"
2. "FM" or "AM"
3. Move the Controller to the left.
4.  "Save station"
The storage list is displayed.
5. Select the desired memory location.



Storing a station that is not being played

1.  "Media/Radio"
2. "FM" or "AM"
3. Highlight the desired station.
4. Press the Controller and hold until the storage list is displayed.
5. Select the desired memory location.

The stations can also be stored on the programmable memory buttons, see the Owner's Manual for the vehicle.



Selecting a station manually

Station selection via the frequency.

1.  "Media/Radio"
2. "FM" or "AM"
3. Move the Controller to the left.
4.  "Manual search"
5. To select the frequency: turn the Controller.
6. To store the frequency: press the Controller.

Renaming a station

When storing a station with RDS signal, the RDS information transferred during storing is accepted as the station name. The station name can be changed.

1.  "Media/Radio"
2. "FM"
3. Select the desired station.
4.  Press the button.
5. "Rename to:"
If necessary, wait until the name of the desired station appears.
6. Press the Controller to store this name.

Additional station information

Concept

If a radio station broadcasts radio text or radio text plus, this information can be displayed, for instance the track or performer of the music. Availability, content and sequence are set by the radio station.

Displaying additional station information

1.  "Media/Radio"
2. "FM"
3. Select the desired station.
4.  Press the button.
5. "Station info"

HD Radio™ reception

Concept

Many radio stations broadcast both analog and digital signals.

General information

When setting a station with a digital signal, it may take a few seconds before the station plays in digital quality.

Information about HD Radio stations whose station name ends with ...HD or with ...HD1:


In areas in which the station is not continuously received in digital mode, the playback switches between analog and digital reception. In this case, switch off digital radio reception.

Information about HD Radio multicast stations whose station name ends with ...HD2, ...HD3, ...:

In areas in which the station is not continuously received in digital mode, there may be interruptions of the audible signal lasting

several seconds. The duration of the interruption depends on the reception.

Activating/deactivating digital radio reception

1.  "Media/Radio"
2. "FM" or "AM"


Depending on the vehicle equipment and country version, it may not be possible to receive AM stations.

3.  Press the button.
4. "HD Radio reception"


 This symbol is displayed in the status line when the audio signal is digital.

Displaying additional information


Some stations broadcast additional information on the current track, such as the name of the artist.

1.  "Media/Radio"
2. "FM" or "AM"

Depending on the vehicle equipment and country version, it may not be possible to receive AM stations.

3. Select a station.
4.  Press the button.
5. "Station info"

License conditions

 **HD Radio**® HD Radio Technology manufactured under license from iBiquity Digital Corporation. U. S. and Foreign Patents. HD Radio™ and the HD, HD Radio, and "Arc" logos are proprietary trademarks of iBiquity Digital Corp.

Satellite radio

General information

Before a channel can be played, you must subscribe to it via telephone. Several channels can be combined into specified packages.


Managing a subscription

General information

In order to enable or unsubscribe from channels, you must have reception. It is usually at its best when you have an unobstructed view of the sky. The channel name is displayed in the status line.

Enabling channels

1.  "Media/Radio"
2. "Satellite radio"

3.  Press the button.
4. "Show subscription info"

The phone number and identification number of the radio are displayed.

5. Call the phone number to have the channel enabled.

You can unsubscribe from the channels again via this phone number.

Unsubscribing from channels

1.  "Media/Radio"
2. "Satellite radio"


3.  Press the button.
4. "Show subscription info"

The phone number and identification number of the radio are displayed.

5. Call the phone number to cancel your subscription to the channel.

Selecting channels

You can only listen to enabled channels.



1.  "Media/Radio"
2. "Satellite radio"
The last channel played will be played back and the channel list displayed.
3. Select the desired channel from the channel list.

To display information about the selected channel:

1. Highlight a channel.
2.  Press the button.
3. "Channel information"

Adjusting display of the channel list

The display of the playback list can be adjusted.

1.  "Media/Radio"
2. "Satellite radio"
3. Move the Controller to the left.
4.  "Change view"
5. Select the desired display:
 - "Channel"
The name of the channel will be displayed.
 - "Artist"
The name of the artist playing will be displayed.
 - "Titles"
The name of the track playing will be displayed.

Changing the channel



 Press the button on the radio.

The next and/or previous channel from the channel list is played.


Storing a channel

1.  "Media/Radio"
2. "Satellite radio"

A symbol on the highlighted channel indicates whether the channel has already been stored.

Symbol	Meaning
	Channel is not stored.
	Channel is already stored.

To store the channel played:


1. Move the Controller to the left.
 2.  "Save station"
The storage list is displayed.
 3. Select the desired memory location.
- Or:

1. Highlight the played channel.
2. Press the Controller.
The storage list is displayed.
3. Select the desired memory location.

To store a channel other than the one played:



1. Highlight the desired channel.
2. Press the Controller and hold until the storage list is displayed.
3. Select the desired memory location.

Or:

1. Highlight the desired channel.
2.  Press the button.
3. "Save in presets"
The storage list is displayed.
4. Select the desired memory location.

The stations can also be stored on the programmable memory buttons.

Selecting a category

1.  "Media/Radio"
2. "Satellite radio"
3. Move the Controller to the left.
4.  "Category"
5. Select the desired category.
The subscribed channels from this category are displayed.
6. Select the desired channel.

Timeshift



General information

The channel you are currently listening to is stored in a buffer for up to an hour.

Prerequisite: the signal must be available.

The stored audio track can be played with a delay following the live broadcast. When the memory is full, the older tracks are overwritten. The memory is cleared when a new channel is selected or when the vehicle is switched off.

Opening the timeshift function

1.  "Media/Radio"
2. "Satellite radio"
3. Move the Controller to the left.
4.  "Time shift"

Time shift forward/reverse

Within the stored recording, it is possible to jump to any point in time.




 Press the button on the radio or turn the Controller.

You can jump to the next or the previous track.

 Press and hold the button on the radio.

The recording is spooled forward or back.

Timeshift menu



Symbol	Function
	Go to the live broadcast.
	Automatic timeshift deactivated/activated.
	Playback/pause.

Automatic timeshift

With automatic timeshift, audio playback is paused for the following events.

- Incoming and outgoing telephone calls.
- Activation of the voice activation system.
- Muting.

After that, audio playback is continued from the time of the interruption.

1. Move the Controller to the left.
2. To activate:
 -  "Automatic time shift"
 - Deactivate:
 -  "Automatic time shift".

Smart Favorites

General information

A maximum of 6 channels can be stored as Smart Favorites.


If a stored channel is selected, the current track will be played from the beginning.

Adding the current channel to Smart Favorites



1.  Press the button.

2. "Add to Smart Favorites"

Removing the current channel from Smart Favorites

1.  Press the button.
2. "Remove from Smart Favorites"

Selecting Smart Favorite

1.  "Media/Radio"
2. "Satellite radio"
3. Move the Controller to the left.
4.  "Category"
5. Select a Smart Favorite.
The subscribed channels from this category are displayed.
6. Select the desired channel.



Favorites

General information



A performer, a track, a league or a team can be stored as a favorite. If the stored favorite is played on a channel, a message appears on the Control Display. Up to 30 Favorites can be stored.

Storing the artist or track



It is only possible to store Favorites that are currently being broadcast. The channel information must be available.

1.  "Media/Radio"
2. "Satellite radio"
3. Move the Controller to the left.
4.  "Add to favorites"
5. Highlight the performer or track, and press the Controller.

A symbol indicates whether the artist and track were already stored.



Symbol	Meaning
	Artist/track is not stored.
	Artist/track was already stored.

Storing the league or team

1.  "Media/Radio"
2. "Satellite radio"
3. Move the Controller to the left.
4.  "Add to favorites"
5. "Add sports information"
6. Select the type of sport desired.
7. Select the desired team.

Activating/deactivating a notification

A notification can be displayed when a selected favorite is being played.

1.  "Media/Radio"
2. "Satellite radio"
3.  Press the button.
4. "Manage favorites"
The stored Favorites are displayed.
5. "Activate alert"
Set a check mark to activate notification for the selected Favorites.
Remove the check mark to deactivate notification for the selected Favorites.
6. Select the desired Favorites.

Opening the Favorites

If an activated favorite is played back, the following message is displayed for approx. 20 seconds: "Favorite on air!".

To change to the played Favorites:

Tap on the message on the Control Display.

Or:

1. Move the Controller to the left.


2.  "Favorite alert"

Select the symbol while the message is shown.

The displayed favorite is played.

When the message disappears, the list of channels that is currently playing one of the stored Favorites can be displayed.

1. Move the Controller to the left.

2.  "Category"

3. Select the Favorites list.

The channels that are currently playing a favorite are displayed.

4. Select the channel that you would like to change to.

Deleting Favorites1.  "Media/Radio"

2. "Satellite radio"

3.  Press the button.

4. "Manage favorites"

The stored Favorites are displayed.

5. Highlight the desired favorites.

6.  Press the button.

7. "Delete entry"

Traffic Jump**General information**

Traffic and weather information for a selected region is broadcast every few minutes.

Selecting a region1.  "Media/Radio"

2. "Satellite radio"

3.  Press the button.

4. "Configure jump"

5. Select the desired region.

Activating/deactivating Traffic Jump

You must have reception in order to activate or deactivate.

1.  "Media/Radio"

2. "Satellite radio"

3.  Press the button.

4. "Configure jump"

5. "Jump to:"

Place a check mark to activate Traffic Jump.

Information for the selected region is broadcast as soon as it is available.

Remove the check mark to deactivate Traffic Jump.

Channel magazine

In the channel magazine, the current and subsequent program for each channel booked is displayed.

1.  "Media/Radio"

2. "Satellite radio"

3. Move the Controller to the left.

4.  "SiriusXM program guide"**Automatic update**

About twice a year, Sirius performs an update of the channel names and positions. The update takes place automatically and may take several minutes.

System limits

- Reception may not be available in some situations, such as under certain environmental or topographical conditions. The satellite radio has no influence on this.


- Graphical contents can be received under certain circumstances.
- The signal may not be available in tunnels or underground garages next to tall buildings or near trees, mountains or other powerful sources of radio interference.

Stored stations



General information

Up to 40 stations can be stored.

Selecting a station

1.  "Media/Radio"
2. "Presets"
3. Select the desired station.

Deleting a station

1.  "Media/Radio"
2. "Presets"
3. Highlight the station you want to delete.
4.  Press the button.
5. "Delete entry"

Audio

Vehicle features and options




This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

Music tracks, audio books, and podcasts can be played back. Sound is played back through the vehicle loudspeakers.

Settings are stored for the driver profile currently used.

Depending on the vehicle equipment, the following audio sources can be used:

Symbol	Meaning
	USB storage device.
	Music interface for smartphones.
	Bluetooth audio.

USB storage device

Playable formats

MP3, MP4, M4A, M4B, AAC, WMA.

Apple iPod/iPhone

The music search and playback of Apple iPod/iPhone are supported.

Audio player and storage media with USB port

Information on all music tracks, for instance artist, genre or track, as well as playback lists, are transmitted into the vehicle. This may take some time, depending on the USB storage device, file size, and number of tracks.

During the transfer, the tracks can be called up via the file directory.

The information for approx. 40,000 tracks can be stored in the vehicle. However, a maximum of 16,000 tracks can be stored per USB storage device.

Music tracks with integrated Digital Rights Management DRM cannot be played.

Selecting the USB storage device

For information about the USB port, see Owner's Manual for the vehicle.

1. Connecting USB storage devices to the USB port.

The adapter cable supplied with the USB storage device would be ideal.

2.  "Media/Radio"
3. "USB"

Or:

Select the name of the USB storage device.

Further playback descriptions, refer to page [47](#).

Bluetooth audio

General information

- Playback of music files on external devices such as audio devices or mobile phones via Bluetooth.
- The volume of the sound output depends on the device. If necessary, adjust the volume on the device.
- Up to four external devices can be connected to the vehicle.

Functional requirements


- Bluetooth device is connected to the vehicle. Bluetooth connections, see Owner's Manual for the vehicle.
- Bluetooth audio playback was activated.

Selecting the Bluetooth device

1.  "Media/Radio"
2. Select the desired Bluetooth device from the list.

Further playback descriptions, refer to page 47.

If the Bluetooth device is not listed in the device list, Bluetooth audio playback may have not been activated. To activate Bluetooth audio playback, proceed as follows:

1.  "Media/Radio"
2. "Manage mobile devices"
3. Select the desired Bluetooth device.
4. "Bluetooth® audio"

Playback

General information

Once an audio source has been selected, information on playback appears on the Control Display.

Information available for the current track followed by the playback list is shown on the Control Display. Content and scope of the playback list depend on the type of the selected playback source and the search criteria applied.

For USB and Bluetooth devices, as well as for the music hard disk, the selected playback list is displayed. This can be the result of a search or of a previously stored playback list.

Further functions are displayed by moving the Controller to the left. The scope of these functions depends on the selected audio source.

Depending on the supported Bluetooth version, some Bluetooth device functions may not be available when using the Central Information Display (CID). If necessary, the missing functions can be accessed directly on the device itself.

Selecting a track

Select the desired track from the playlist.

Starting with the selected track, all tracks of the playback list are played.

Changing the track

On the radio:



Press the left or right button.

The previous or next track from the playlist is played.

Fast forward/reverse

On the radio:



Press and hold the left or right button.

Search criteria

General information

The possible search criteria depend on the selected audio source.

Searching for track information

The following search criteria refer to the data stored in the track information.

1. Move the Controller to the left.
2. 🔍 "Media search"
3. Select the desired setting:
 - "Search"

All the tracks containing the search string are displayed. Entering more characters will continue to narrow down the search results.

Tilt the Controller to the right to display the list of results.
 - "Genres"

A list of all available genres is displayed.

Select a genre to display all respective artists.
 - "Artists"

A list of all available artists is displayed.

Select an artist to display all respective albums and tracks.
 - "Albums"

A list of all available albums is displayed.

Select an album to display all respective tracks.
 - "Titles"

A list of all available tracks is displayed.

4. Select album, if needed.
5. Select the track at which the playback is going to begin.

The search for artists and titles can also be selected directly.

1. Move the Controller to the left.
2. 🎵 "Artists" or 🎵 "Titles"

Tracks where the selected search criterion is not stored are summarized under "unknown". Tracks without track information can only be found via the directory structure.

Search playlists

1. Move the Controller to the left.
2. 🔍 "Media search"
3. "Playlists"

A list of all available playback lists is displayed.
4. Select the playback list.
5. Select the track at which the playback is going to begin.

Information on playback appears on the Control Display. A playback list is created from the search results.

Search audio books and podcasts

Depending on the USB storage device and equipment, separate audio book and podcast searches are possible.

1. Move the Controller to the left.
2. 🔍 "Media search"
3. Select the desired setting:
 - "Podcasts"

A list of all available podcasts is displayed.
 - "Audio books"

A list of all available audio books is displayed.


4. Select the track at which the playback is going to begin.

Information on playback appears on the Control Display. A playback list is created from the search results.


Search directory structure

It is possible to search the music hard disk and USB storage devices via the directory structure.

The names of folders and tracks correspond to folder and file names. The folder and file names can deviate from the names in the track information.


1. Move the Controller to the left.
2.  "Media search"
3. "Browse folder"
4. Change into a sub folder, if needed.
Select the track at which the playback is going to begin.
Information on playback appears on the Control Display. A playback list is created from the search results.

Scroll through albums

1. Move the Controller to the left.
2.  "Browse albums"
Available albums are graphically presented.
3. Turn the Controller to scroll through the albums.
4. Select the desired album.
All tracks of the selected album are displayed.
5. Select the track at which the playback is going to begin.
6. Move the Controller to the left. The Control Display shows information on play-

back. The playback list corresponds to the track list of the album.

Searching for similar tracks

1. Move the Controller to the left.
2.  "Similar titles (local)"
A list with similar tracks is displayed.
3. Select the track at which the playback is going to begin.
Information on playback appears on the Control Display. A playback list is created from the search results.

Random playback

Concept

The current playlist or all tracks of the selected audio source are played back in random order.

Select random



1. Move the Controller to the left.
2.  "Shuffle"

Favorites list

Concept

The current track can be assigned to a special playback list, the Favorites list. If the current track already belongs to the Favorites list, it can be deleted from this list. The Favorites list is displayed first when searching for playback lists, refer to page 48.

Creating the Favorites list

1. Move the Controller to the left.
2.  "Add to favorites" or  "Delete from favorites"

Telephone

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

Telephone functions

General information

Mobile phones can be connected to the vehicle via Bluetooth, see Owner's Manual for the vehicle.

At high temperatures, the charge function of the mobile phone can be limited where appropriate and functions are no longer executed.

Do not operate a mobile phone that is connected to the vehicle on the mobile phone keypad, as this may lead to a malfunction.

When the mobile phone is used via the vehicle, refer to the owner's manual of the mobile phone.

Safety information

Warning

Operating the integrated information systems and communication devices while driving can distract from traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or

devices when the traffic situation allows. As warranted, stop and use the systems and devices while the vehicle is stationary.

Incoming call

If the number of the caller is stored in the phone book and is transmitted by the network, the name of the contact is displayed. Otherwise, only the phone number is displayed.

Accepting a call

Incoming calls can be answered in several ways.

- Via Central Information Display (CID):

 "Accept"



Press the corresponding button on the steering wheel.

Rejecting a call

"Reject"

Ending a call

- Via Central Information Display (CID):

 "End call"




Press the corresponding button on the steering wheel.

Last calls

The last outgoing, missed, and incoming calls are transferred to the vehicle. Depending on the equipment, the calls are transferred from the main phone and additional phones.

Displays

1.  "Communication"
2. "Recent calls"
3. The 20 last calls are displayed.

Filtering call list

1. "Calls:"
2. Select the desired setting.


Selecting number from list

Select from list. Call is established via the mobile phone, from where the entry originates.

Via options: start call via the second mobile phone.

To cancel: "End call"

Storing as contact or adding to contact


1. Highlight the telephone number.
2.  Press the button.
3. "Save as new contact" or "Add to contact"

Active calls

Adjusting the volume



Turn the volume button on the radio during the call, until the desired volume is reached. The setting is stored for the driver profile currently used.

Automatic volume equalization


1.  "My MINI"
2. "System settings"
3. "Tone"
4. "Volume settings"
5. "Microphone" or "Speakers"

6. To adjust: turn the Controller.
7. To store: press the Controller.

Dialing a number



1.  "Communication"
2. "Dial number"
3. Enter the numbers.
4.  Select the symbol.
The connection is established via the mobile phone to which this function has been assigned.

Establish the connection via the additional phone:

1.  Press the button.
2. "Call via"


Holding, resuming

An active call can be put on hold and resumed later on.

-  "Hold/Resume"
Call is put on hold.
-  "Hold/Resume"
Call is resumed.

Muting the microphone

When a call is active, the microphone can be muted.

-  "Microphone"
The muted microphone is automatically activated:
- When a new connection is established.
- When switching between call parties.

DTMF suffix dialing

DTMF suffix dialing can be used for gaining access to network services or for controlling devices, for instance to make a remote

inquiry of an answering machine. The DTMF code is needed for this purpose.

1. ☐ "Keypad dialing"
2. Enter DTMF code.

Calls with multiple parties

General information

You can switch between calls or connect two calls to a single conference call. These functions must be supported by the mobile phone and service provider.

Accepting a call while speaking to another party

If a second call comes in during an ongoing call, a call waiting signal sounds where appropriate.

☎ "Accept"

The call is accepted and the existing call is put on hold.

Establishing a second call

An additional call can be established while a call is active.

1. ☐ "Contacts"
2. Select new number.

The call is started and the first call is put on hold.

Switching between two calls, hold call

You can switch between two calls.

1. Establish two calls.
2. "Resume"

The call on hold is resumed.

Establishing a conference call

Two calls can be connected to a single telephone conference call. The calls must be made from the same mobile phone.

1. Establish two calls.
2. ☎ "Conference call"

Hands-free system

General information

Calls that are being made on the hands-free system can be continued on the mobile phone and vice versa.

From the mobile phone to the hands-free system

Calls that were begun outside of the Bluetooth range of the vehicle can be continued on the hands-free system with standby state or the ignition switched on. The vehicle key must be located in the vehicle for this to work.

Depending on the mobile phone, the system automatically switches to the hands-free system.

If the system does not switch over automatically, follow the instructions on the display of the mobile phone. Refer also to the owner's manual of the mobile phone.

From the hands-free system to the mobile phone

Calls that are made on the hands-free system can in some cases be continued on the mobile phone; this depends on the mobile phone.

Follow the instructions on the display of the mobile phone. Refer also to the owner's manual of the mobile phone.

Contacts

General information

Contacts can be created and edited. The contacts from the mobile phone are additionally transferred and displayed. Contact pictures can be displayed, if the mobile phone supports this function.


Displaying all contacts

1.  "Communication"
2. "Contacts"

The contacts are listed in alphabetical order. Depending on the number of contacts, contact search and quick search are offered.

Contact search

Contact search is available with more than 30 contacts.

1.  "Search"
2. Enter the letters.
The hits are displayed on the right side.
3. Move the Controller to the right.
4. Select the contact to display it.

Quick search in lists


Quick search is available starting from 30 contacts. All letters, for which there are entries, are displayed in alphabetical order on the left of the Control Display.

1. Turn the Controller to the left or right quickly.
All letters, for which contacts are stored, are displayed on the left.
2. Select the first letter of the desired contact.

The first entry of the selected letter is displayed.

Sorting contacts

Contact names can be displayed in a different order. Depending on how the contacts were stored on the mobile phone, the sorting order of the contacts may differ from the selected sorting order.

1.  Press the button.
2. "Sort contacts"
3. "Last name" or "First name"

Checking the address as a destination

If the vehicle is equipped with a navigation system, a contact can be adopted as a destination.

1. Select the desired contact.
2. Select the address.
3. "Check address" or "Search for address online"
4. Correct entries, if necessary.
5. "Start guidance"

The address can be used for the destination guidance.

Editing a contact


If a contact is changed, which has been transferred from the mobile phone, a copy of the entry is created in the vehicle during storing.

Contact entries having identical names are combined into one contact.

1. Select the desired contact.
2. "Edit contact"
3. Change the desired entry or add entries.
4. "Save contact in the vehicle"

Showing contact pictures


Pictures stored with the contacts are stored in the vehicle when the mobile phone is connected to the vehicle.


1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. "Settings"
5. "Contact images"
6. Press the Controller.

Voice command response

A connected smartphone can be used via voice operation.

Activate voice command response on the smartphone for this purpose.

Button on the steering wheel	Function
	Press the button for at least 3 seconds. Voice command response is activated on the smartphone.

 The symbol indicates that the voice command response is active.

Additional functions

General information

Depending on the mobile phone, the following contents of the mobile phone are transferred to the vehicle:

- Contacts, refer to page 53.
- Short messages, refer to page 54.
- E-mails, refer to page 55.
- Calendar entries, appointments, refer to page 56.

- Tasks, refer to page 57.
- Notes, refer to page 58.


Data transfer can take several minutes.

Certain functions may need to be enabled by the mobile phone provider or service provider.

Detailed information about which mobile phones are supported is available at www.miniusa.com/bluetooth.



Short messages

Displaying all short messages


1.  "Communication"
2. "Messaging"

Status

A symbol identifies the short message status.


Sym- bol	Meaning
	Read short message.
	Unread short message.

Filtering the message list

1.  Press the button.
2. "Filter messages"
3. Select the desired setting.


Selecting sources

You can choose, whether and from which mobile phone the short messages should be transferred.

1.  Press the button.
2. "Select sources for messages"
3. Select the desired mobile phone.

Deleting a conversation



Completely delete a conversation with a contact.

1. Highlight the desired short message.
2.  Press the button.
3. "Delete text message thread"
4. "Yes"



Displaying a short message

Select the desired short message or conversation. The conversation with this contact is displayed.

Answering or forwarding a short message

1. Select the desired short message.
2.
 -  "Reply"
The recipient of the short message is automatically entered.
 -  "Forward"
"To:"
Enter phone number or contact. Tilt the Controller to the right as needed to select the contact from the list of results.
3. "From:"
Select mobile phone as needed, from which the short message should be sent.
4. "Send"

New short message







1.  "Communication"
2. "Messaging"
3.  "Compose text message"
4. "To:"

Enter phone number or contact. Tilt the Controller to the right as needed to select the contact from the list of results.

5. "From:"
Select mobile phone as needed, from which the short message should be sent.
6. "Send"
To cancel: "Delete all content"

Additional functions

The following functions are available when a short message or conversation is selected.

-  "Call sender"
-  "Add to contacts" or "Show sender"
-  "Forward", refer to page 55.
-  "Reply", refer to page 55.
-  "Delete"
-  Read contents, refer to page 59.
- "Use contact data", refer to page 59.


E-mail

Displaying all e-mails

1.  "Communication"
2. "Email"



Selecting account

You can choose, whether and from which mobile phone and possibly from which user account the e-mails will be transferred.


1.  Press the button.
2. "Select account"
3. Select the desired account.

Status


A symbol identifies the e-mail status.

Sym- bol	Meaning
	Read e-mail.
	Unread e-mail.

Filtering e-mails


1.  Press the button.
2. "Filter emails"
3. Select the desired setting.

Deleting e-mail



1. Highlight the desired e-mail.
2.  Press the button.
3. "Delete email"
4. "OK"

Displaying all recipients

If an e-mail has several recipients, they can be displayed and their data used for further functions.

1. Select the desired e-mail.
2.  Press the button.
3. "Show all recipients"


New e-mail




1.  "Communication"
2. "Email"
3.  "Compose email"
4. "To:"
Enter e-mail address or contact. Tilt the Controller to the right as needed to select the contact from the list of contacts.
5. "From:"
Select account as needed, from which the e-mail should be sent.

6. "Send"

To cancel: "Delete all content"






Answering and forwarding e-mails

1. Select the desired e-mail.
2.  "Reply"

-  "Reply"
The e-mail recipient is automatically entered.
 -  "Reply to all"
All e-mail recipients are automatically entered.
 -  "Forward"
Enter e-mail address or contact. Tilt the Controller to the right as needed to select the contact from the list of contacts.
3. "To:"
Enter e-mail address or contact. Tilt the Controller to the right as needed to select the contact from the list of results.
 4. "From:"
Select mobile phone and user account as needed, from which the e-mail should be sent.
 5. "Send"


Additional functions

The following functions are available for a selected e-mail.

-  "Text-to-speech", refer to page 59.
-  "Reply", refer to page 56.
-  "Add to contacts" or "Show sender"
-  "Mark as unread"
-  "Delete email"

Calendar

Displaying the calendar

1.  "Communication"
2. "Calendar"
The appointments of the current week are displayed.
To display different days in the calendar:
 - "Show previous week"


- "Show next week"

Displaying the calendar month

Select the calendar day.


The monthly overview is displayed. Calendar days with appointments are marked.

Switching to today


1.  Press the button.
2. "Change to today"

Selecting sources


You can choose, whether and from which mobile phone the appointments should be transferred.

1.  Press the button.
2. "Select source"
3. Select the desired mobile phone.

Activating reminders

1.  Press the button.
2. "Activate reminders"
Reminders are displayed in the Messages and in the Status field, see Owner's Manual for the vehicle.

Deactivating reminders

1. Select the desired calendar entry.
2.  "Deactivate reminders"

Updating the calendar

Update data, refer to page 59.

Additional functions


Depending on the vehicle equipment, the following functions are available in a selected appointment:

-  Read contents, refer to page 59.

- Start destination guidance.
- "Use details", refer to page 59.

Tasks


Display tasks

1.  "Communication"
2. "Tasks"
All tasks are displayed.

Sorting tasks

1. "Sorted by"
2. Select the desired setting.

Activating reminders


1.  Press the button.
2. "Activate reminders"
Reminders are displayed in the Messages and in the Status field, see Owner's Manual for the vehicle.

Updating tasks

Update data, refer to page 59.


Selecting sources

You can choose, whether and from which mobile phone the tasks should be transferred.

1.  Press the button.
2. "Select source"
3. Select the desired mobile phone.

Additional functions

The following functions are available in a selected task.

-  Read contents, refer to page 59.
- "Use contact data", refer to page 59.

Notes

Displaying all notes

1.  "Communication"
2. "Memos"


All voice notes and text notes are displayed.

Exporting all voice notes


In order to export voice notes via the USB port, a compatible device must be connected to the USB port.

Voice notes already existing on the USB storage device are overwritten during exporting.




- Compatible devices: USB mass storage devices, such as USB flash drives or MP3 players with a USB port.
- Non-compatible devices: USB hard drives, USB hubs, USB memory card readers with multiple slots, Apple iPod/iPhone.
- File systems: popular file systems for USB media are supported. The FAT32 format is recommended.

1.  Press the button.
2. "Export all memos (USB)"

Deleting all voice notes

1.  Press the button.
2. "Delete all voice memos"
3. "OK"

New voice note

1.  "New voice memo"
2.  "Start recording"/"Resume recording"
3.  "Pause recording"
4. "Save"

The voice note is displayed in the list of voice notes.





To cancel: "Cancel"

Displaying a note

Select the desired note.

Additional functions

The following functions are available when a voice note is selected.

-  "Email with voice memo", refer to page 56.
-  "Export (USB)", refer to page 58.
-  "Delete"
-  "Play", refer to page 59.

Updating notes

Update data, refer to page 59.

Text recognition/dictation function

General information

The offering depends on the equipment version of the vehicle and the country-specific variant.

Concept








Spoken words are detected by voice recognition and converted into text. The text can be corrected and supplemented as required. The text can be used as subject or content of e-mails or short messages. To use the functions, data is transmitted to a service provider via an encrypted connection and stored locally there.

Functional requirement

The mobile phone must support the function.

The following function is activated: "Server speech recognition"

Recording texts

1.  Select the desired language.
2.  Select the symbol to start the recording.
3.  Select the symbol to end the recording.
4. **OK** "Confirm text"
5.
 -  "Delete last dictation"
 -  "Delete all"
 -  "Read out full text"
 -  "Read out last dictation"


Improving voice recognition for contact names

Concept

The contact names of the connected mobile phones are transmitted to voice recognition. This improves the recognition of contact names during text conversion. To use the functions, data is transmitted to a service provider via an encrypted connection and stored locally there.




Activating/deactivating the function


The function can be activated or deactivated for the respective mobile phone.

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. Select the desired device.
5. "Contact upload for messaging"

Reading out loud





SMS, e-mail, tasks, text notes, and calendar entries can be read out loud.

-  "Play"
-  "Pause"
-  "Next section"/"Next element"

-  "Previous section"/"Previous element"
- Move the Controller to the left to end.



Playback

Voice notes can be played.

-  "Play"
-  "Pause"
-  "Fast forward"
-  "Fast rewind"

Updating data

Notes, tasks, and appointments of the calendar can be updated.

1.  "Communication"
2. Select the desired setting:
 - "Calendar"
 - "Tasks"
 - "Memos"
3.  Press the button.
4. "Update data"

Using data

Phone numbers, mail addresses in calendars, short messages, etc., can be used in other functions.

While driving:

1. Select the desired element, for instance a short message.
2. "Use contact data"
3. All usable data is displayed.
4. Highlight the desired element, for instance a phone number.
5. Move the Controller to the right. All available options are displayed.
 - "Compose email"
 - "Compose text message"


- "Add to contact"
- "Save as contact"
- "Call number in message"

6. Select the desired setting.

The elements can be individually selected when the vehicle is stationary. The available options are displayed.

Adjusting the menu

The menu can be adapted, for instance to remove entries from the menu for functions not being used.

1.  "Communication"
2. "Personalize menu"
3. Select the desired setting.

MINI Connected

Vehicle features and options

This chapter describes all standard, country-specific and optional features offered with the series. It also describes features and functions that are not necessarily available in your vehicle, e.g., due to the selected options or country versions. This also applies to safety-related functions and systems. When using these functions and systems, the applicable laws and regulations must be observed.

General information

The Teleservices features, intelligent emergency call or an active MINI Connected contract are required to use the services and applications described here.

The content and scope of the services that are available may vary by country. Therefore, it is possible that some of the services and applications described in the Owner's Manual may not be offered, or not yet be offered, in the vehicle's country of registration.

Details on the content and scope of MINI Connected can be obtained from www.mini-usa.com/connectivity or your service center.

Safety information

Warning

Operating the integrated information systems and communication devices while driving can distract from traffic. It is possible to lose control of the vehicle. There is a risk of accident. Only use the systems or devices when the traffic situation allows. As warranted, stop and use the systems and devices while the vehicle is stationary.

MINI Teleservices

Concept

Teleservices are services that help to maintain vehicle mobility.

General information

The offering depends on the equipment version of the vehicle and the country-specific variant.

For further information on the available services, the vehicle manufacturer recommends contacting a service center or customer support.

Teleservices can comprise the following services:

- Service Request, refer to page 62.
- Teleservice Report, refer to page 62.
- Teleservice Battery Guard, refer to page 63.
- Your dealer's service center, refer to page 63.

- Roadside Assistance, see Owner's Manual for the vehicle.

Requirements

- Active MINI Connected contract or equipment version with intelligent emergency call.
- Cellular network reception.
- Ignition or standby state is switched on.

Service Request

Automatic Service Request

The Teleservice data on the vehicle's service notifications is sent automatically to the service center by MINI prior to the service deadline. If feasible, the service center will contact the customer about arranging a service appointment.

This way, the dealer's service center can plan the necessary work in advance. This shortens the duration of the service appointment.

Manual Service Request

Concept

Using a manually initiated Service Request, data on the vehicle's service notifications is directly sent by MINI to the service center. If feasible, the service center will contact the customer about arranging a service appointment.

General information

A Service Request can also be started via a Check Control message, see Owner's Manual for the vehicle.

Carry out service registration via the Check Control message: "Service request".

Starting a Service Request

1.  "MINI Connected"

2. "MINI Assist"
3. "Teleservice Call"



Last Service Request

Concept

The last Service Request, for instance the last report to the dealer's service center, can be displayed on the Control Display.

Displaying the last Service Request

Check to see when the last Service Request was transmitted.

1.  "My MINI"
2. "Vehicle status"
3. Move the Controller to the left.
4.  "Teleservice Call"

Teleservice Report

Concept

Transmits technical data that is evaluated for the ongoing development of MINI products from the vehicle to MINI in regular intervals, if needed.

General information

The Teleservice Report is free of charge and is activated in vehicles that meet the following requirements:

- Certain technical requirements are met.
- Active MINI Connected contract.
- Equipped with intelligent emergency call.

Neither personal data nor position data is transmitted.

Teleservice Battery Guard

Concept

If the battery charge state falls below certain values, MINI will inform you or your dealer's service center directly as warranted or the next time the vehicle is started.

General information

If necessary and possible, the dealer's service center will contact you to arrange a service appointment.

The Battery Guard Teleservice is available on a country-specific basis and under the following conditions:

- Certain technical requirements are met.
- Active MINI Connected contract.
- To receive information from the Battery Guard Teleservice, your contact data must be stored in the MINI Connected customer portal.

Your dealer's service center

Concept

The preset service center is displayed. It is possible to contact the service center.

General information

To use Service Partner management in the vehicle, log in with the MINI Connected access data in the MINI Connected customer portal. In addition, your vehicle must be assigned to your account in the MINI Connected customer portal.

Displaying service centers




The service center that is currently assigned to the vehicle is displayed as a contact in the vehicle.

1.  "MINI Connected" or  "Communication"

2. "MINI Assist"
3. "Your service center" or select service partner management if necessary.

The assigned service center is displayed along with all its contact information.

Depending on the vehicle equipment, the following functions are available in a contact:

-  "Start guidance"
-  Call contact.
-  "Compose email"

Updating MINI Assist

Concept

Starts the manual update of all services available in the vehicle.

Updating services


1.  "MINI Connected"
2.  Press the button.
3. "Update MINI Services"

Customer support

Concept

Contact customer support for information on all aspects of your vehicle.

Calling customer support

1.  "MINI Connected"
2. "MINI Assist"
3. "Customer support"

The customer support is displayed and a voice connection is established. If a voice connection is not established, dial the number manually.

MINI Connected Services

Functional requirements

- MINI Connected Services has been activated.
- Cellular network reception.
- For certain services, the vehicle must be able to determine its current position, for instance in order to receive information about the current location.

MINI Connected Store


Concept

In vehicles with specific technical requirements, various services can be booked later.

General information

The range of services offered depends on the country.

Ordering services

1.  "MINI Connected"
2. To purchase a service, select it and follow the instructions on the Control Display.



Messages

General information

Messages from the Concierge service are displayed.



Information about the short messages from the mobile phone, refer to page 54.

Displaying messages


1.  "MINI Connected" or  "Communication"
2. "MINI messages"
The most recent messages are displayed.

Status

A symbol identifies the message status.

Sym- bol	Meaning
	Read message.
	Unread message.


Filtering message list by status

1.  Press the button.
2. "Filter MINI messages"
3. Select the desired setting.

Filtering message list by message type


1. "Filter"
2. Select the desired setting.

Deleting a message

1.  Press the button.
2. Delete highlighted message: "Delete message"
Delete all messages: "Delete all messages"

Additional functions

Depending on the vehicle equipment, the following functions are available in a selected message, from Concierge service, for instance.

-  Select the location to start destination guidance.
- Select phone number to make a call.

Vehicle apps

Concept

MINI Connected Services offer the option to display information, for instance regarding

the weather or news, on the Control Display using apps and other functions.



Displaying MINI Connected Services apps

1.  "MINI Connected"
2. Select desired app.

Registering

To display personal data such as e-mails, it is necessary to log on.

This function is country-specific.

1.  "MINI Connected"
2.  Press the button.
3. "Login"
4. "User:"
Enter the user name.
5. "Password:"
Enter the password.
6. "OK"



Registering automatically

Registration is performed automatically when the vehicle app is opened.

"Auto-login"


The "Auto-login" function can be deactivated in the MINI Connected portal on the Internet. A change may be required in the customer portal under Password protection in the vehicle in the Control menu item.

Deregistering

1.  "MINI Connected"
2. "Vehicle apps"
3.  Press the button.
4. "Logout"

Adjusting the menu

The menu can be adapted, for instance to remove entries from the menu for functions not being used.

1.  "MINI Connected"
2. "Personalize menu"
3. Select the desired setting.
4. Move the Controller to the left.

Remote Services

Concept

Remote Services enable some vehicle functions to be controlled remotely via the MINI Connected app. The app can be used to lock and unlock the vehicle, for instance.

Other functions may be available, depending on the vehicle.

General information

The vehicle is controlled via the MINI Connected app, which you can obtain from the Apple App Store for iOS and from the Google Play Store for Android.

Remote Services must first be activated in the MINI Connected app or, depending on the country, in the customer portal on the Internet before they can be used. An active MINI Connected contract is required.

Alternatively, remote control of certain functions can also be requested via the MINI Connected Call Center.

Concierge service

Concept

The Concierge service offers information on events, gas stations or hotels, and provides phone numbers and addresses. A voice con-

nection to the Concierge service is established for this purpose. Many hotels can be booked directly by the Concierge service. The Concierge service is part of the optional Response Center Plan.

Starting Concierge service

1. "MINI Connected"
2. "Concierge"

A voice connection to the Concierge service is established.

Apple CarPlay preparation

Concept

CarPlay allows certain functions of a compatible Apple iPhone to be used via Siri voice operation and the Central Information Display (CID).

General information

Depending on the country-specific version, CarPlay may not be available. Contact a dealer's service center or another qualified service center or repair shop for more detailed information.

The iPhone provides CarPlay and any associated apps. The scope and content depend on the device manufacturer and can vary depending on the country-specific version.

The following restrictions apply to an iPhone connected via CarPlay:

- Not every app installed on the iPhone can be used via CarPlay.
- Calling is only possible via CarPlay.
- The iPhone cannot be paired as additional phone.
- The phone book entries are not transferred into the vehicle.

- Only one additional phone can be connected with the vehicle.
- Using CarPlay can incur mobile telephony costs. These costs are not a part of the optional vehicle feature.

Functional requirements

The iPhone is connected to the vehicle, see Owner's Manual for the vehicle.

Selecting CarPlay


CarPlay can be selected via the following menus:

- In the main menu of the vehicle.
 - 📍 "Apple CarPlay"
The CarPlay menu is displayed.
 - 🎵 "Media/Radio"
"Apple CarPlay"
The iPhone music app opens.
 - 📍 "Navigation"
"Maps in Apple CarPlay"
The iPhone navigation app opens.
 - 📞 "Communication"
"Phone in Apple CarPlay"
The iPhone phone app opens.

Using CarPlay


CarPlay can be used via the Central Information Display (CID) and voice operation.

Via voice operation:

1. Press and hold the  button on the steering wheel, until the Siri Voice command response is activated on the iPhone.
2. Say the commands familiar from the iPhone.



Switching CarPlay off/on

To use the iPhone without CarPlay, CarPlay must be switched off.

1.  "My MINI"
2. "System settings"
3. "Mobile devices"
4. Select the iPhone with CarPlay function.
5. – "MINI on-board monitor"
 - Select the entry to switch CarPlay off. The iPhone remains connected as a smartphone.
 - "Apple CarPlay"
 - Select the entry to switch CarPlay on.

Exiting CarPlay

The following options are available for exiting CarPlay without switching CarPlay off:

-  Press the button on the Controller.
- Select the MINI symbol in the CarPlay main menu.
-  Press the button on the Controller when the CarPlay main menu is displayed.

MINI Connected app

Concept

The Connected app provides mobility-based services and applications.

General information

You can find information on installing the Connected app and on its content, plus information on the ConnectedDrive customer portal, at www.mini.com/connected.

The Connected app must be installed on the smartphone you wish to use. The installation process depends on the smartphone.

To use all the features of the Connected app, you will need to register when you start it up; you only need to do this once. The registration process creates a personal MINI Connected account in the MINI Connected Customer Portal. If a MINI Connected account already exists, its login data can be used for the Connected app.

A unique assignment of the app to the vehicle requires the input of the vehicle identification number.

Some functions enable communication with the vehicle without the need for you to be inside or at the vehicle. These functions can be executed via the Connected app or the MINI Connected account in the MINI Connected Customer Portal on the Internet.

The vehicle needs to be linked to the MINI Connected account in order to use the functions; you only need to do this once. You can link the vehicle via the MINI Connected account in the MINI Connected Customer Portal or via the app. Confirmation in the vehicle via Central Information Display is also required.

MINI Connected Apps

Concept

Certain apps of a compatible smartphone can be integrated in the vehicle. These apps are shown on the Control Display.

General information

For reasons of safety, some apps are usable only while the vehicle is stationary.

The manufacturer of your vehicle recommends the use of apps that MINI has determined to be compatible with your vehicle;

otherwise, there may be malfunctions in system operations.

Information on using apps:

- The functional scope shown on the Control Display depends on the scope of the app installed on the smartphone.
- The data transfer of the apps from the smartphone to the vehicle can take some time. Some apps depend on the speed of the available Internet connection of the smartphone.
- Some smartphones cannot simultaneously use apps and the Bluetooth hands-free system. If necessary, restart the app on the smartphone after a phone conversation.
- Using apps on a smartphone can incur costs. These costs are not a part of the optional vehicle feature.


Information on compatibility:

- Compatible smartphones: from a dealer's service center or another qualified service center or repair shop.
- For more information about MINI Connected: www.mini.com/connected.
- From a dealer's service center or another qualified service center or repair shop.

Requirements

- Corresponding mobile contract.
- Compatible smartphone.
- Apps are installed on the smartphone and ready for operation.
- The smartphone is connected to the vehicle via USB port or Bluetooth, refer to Owner's Manual for the vehicle.

Use Apps

1.  "MINI Connected"
2. Select desired app on the smartphone.

Displaying the status

1.  "MINI Connected"
2. "Mobile devices"

Frequently Asked Questions

Why are the apps installed on my smartphone not displayed on the Control Display, although the smartphone is connected to the vehicle?

- The smartphone is not selected anymore for using apps.

A different smartphone connected to the vehicle was selected for using apps.

- The smartphone is not selected anymore for using Bluetooth audio.

The smartphone is connected to the vehicle via Bluetooth. A different smartphone connected to the vehicle was selected for using Bluetooth audio.

Without Bluetooth audio, apps cannot be used via a Bluetooth connection.

Two different smartphones are used for audio playback and for using apps. In this case, one of the smartphones has to be connected to the vehicle via the USB port.

- The smartphone is connected to the vehicle via Bluetooth and USB port at the same time.

If the connection is established via the USB port and Bluetooth at the same time, the Bluetooth connection is prioritized.

MINI FindMate

Concept

MINI FindMate includes an electronic luggage label that can be connected to a compatible smartphone using the MINI Connected app.

General information

A distinction is made between whether the luggage tag is situated inside or outside the reception range.

The app offers the following possibilities:

- Whether the luggage tag is situated inside or outside the reception range is shown.
- An alarm can be set for the case in which a luggage tag leaves the reception range.
- An alarm on the luggage tag can be triggered via the smartphone.
- An alarm on the smartphone can be triggered via a button on the luggage tag.
- If a luggage tag leaves the reception range, the position of the smartphone is stored at which the signal of the luggage tag was last received.

Whether or not the luggage tag or smartphone are moved is irrelevant since only the connection between the two is evaluated.

The following situations are examples of uses of this technology:

- The luggage tag is attached to an object that needs to be taken along the next day.

An alarm on the smartphone is triggered as soon as the smartphone leaves the reception range. An alarm on the luggage tag can be triggered via the smartphone to make it possible to find the object quicker.

- The luggage tag is attached to a fixed position that needs to be found again. When leaving the reception range, the last position of the smartphone at which the signal from the luggage tag was received is stored. It is possible to find this position – for example, a forgotten bag – using the smartphone navigation function.

- The smartphone should be found with the aid of the luggage tag.

An alarm on the smartphone is triggered via the button on the luggage tag. For this to occur, the smartphone must be within the reception range.


A detailed description is contained in the tutorial of the MINI Connected app.

Functional requirements

- The insulation underneath the luggage tag battery has been removed.
- The necessary app is installed on a compatible smartphone.
- The luggage tag is paired with the smartphone.

Making the luggage tags ready for use

The luggage tags are delivered with a battery already inserted. To prevent the battery discharging prematurely, the positive terminal is protected by insulation.



1. Open the battery compartment.
2. Remove the insulation underneath the battery.
3. Close the battery compartment.

Connection to the vehicle

If the smartphone is connected to the vehicle, the following information can be displayed on the Control Display:

- A list of the luggage tags paired with the smartphone.
- The last position of the smartphone at which the signal of each luggage tag was received.
- Current forgotten alarms from objects, which may have been missed when leaving the house, for example.

Everything from A to Z

Index

A

Address entry, navigation [7](#)
Alternative routes [17](#)
AM/FM station [38](#)
Announcement, navigation, see Spoken instructions [19](#)
Apple CarPlay preparation, operation [66](#)
Applications, see MINI Connected Apps [67](#)
Appointments, see Calendar [56](#)
App, Remote Services [65](#)
Apps [67](#)
Arrow view, split screen [25](#)
Audio [46](#)
Audio playback, Bluetooth [47](#)
Audio playback, pause [34](#)
Automatic Service Request [62](#)

B

Balance, sound settings [36](#)
Bass, sound settings [36](#)
Battery Guard, Teleservice [63](#)
Bluetooth audio [47](#)

C

Calendar [56](#)
CarPlay, operation [66](#)
Changing the route details [16](#)
Charging recommendation [18](#)
Charging recommendation, navigation [18](#)
Charging stations check [23](#)
Checking the charging stations [23](#)
Communication [50](#)
Concierge service [65](#)
Concierge service messages, see Messages [64](#)

Conference, see Calls with multiple parties [52](#)
ConnectedDrive Store, see MINI Connected Store [64](#)
Connected Services [64](#)
Contacts [53](#)
Customer support [63](#)

D

Default settings, navigation [22](#)
Destination entry by voice [8](#)
Destination entry, GPS coordinates [11](#)
Destination guidance [15](#)
Destination guidance hints, route [20](#)
Destination guidance with intermediate destinations, see Trip [12](#)
Destination input [7](#)
Destination, storing as contact [16](#)
Dictation function [58](#)
Digital radio, see HD Radio reception [39](#)
Dynamic destination guidance [29](#)

E

E-mail [55](#)
Entertainment, control elements [34](#)
Entertainment source, changing [34](#)

F

Fader, sound settings [36](#)
FindMate [68](#)
FM/AM station [38](#)

G

Gong, volume equalization [36](#)
GPS coordinates, destination entry [11](#)

GPS navigation, see Navigation system 6

H

Hands-free system 52

HD Radio 39

Help regarding navigation, see Frequently Asked Questions 32

Home address, navigation 9

Hotline, see Customer support 63

I

Information on the navigation data 24, 31

Interactive map, see Functions in the map view 21

Intermediate destination, navigation 12

iPod/iPhone 46

L

Last charging stations 8

List of destination guidance hints, split screen 25

M

Maneuvering hints, see Destination guidance hints 20

Map, opening for navigation 14

Map update 31

Map view, functions 21

Message list, traffic bulletins 27

Microphone, muting 51

MINI Connected Services 64

MINI Connected Store 64

MINI FindMate 68

MINI Teleservices 61

Mobile phone 50

Mobile phone, operation 50

MP3 player, see Audio 46

N

Navigation data 24, 31

Navigation, split screen 25

Navigation system 6

Notes 58

P

Pause, audio playback 34

Phone conference, see Calls with multiple parties 52

Points of Interest, navigation 9

Q

Quick search 8

R

Radio 38

Radio, adjusting the volume 34

Radio, control elements 34

Radio Data System RDS 38

Radio, muting 34

Radio, tone settings 36

Range assistant 15

Range map 20

RDS Radio Data System 38

Reading out loud 59

Real Time Traffic Information RTTI 28

Recent destinations 7

Remote Services, app 65

Route criteria, route 16

Route details, see Navigation 17

Route magnet, see Changing the route details 19

Route section, bypassing 17

RTTI Real Time Traffic Information 28

S

Satellite radio 40

Search charging stations 9

Select a destination from contacts, navigation 11

Service messages, see Messages 64

Service Request 62

Services, Remote 65

Settings, navigation 22

Short messages 54

Smartphone, operation 50

Software applications, CarPlay 66

Software applications, see MINI Connected Apps 67

Sound output 34

Source, changing, see Entertainment source, changing 34

Speech recognition 58

Speed Volume, volume equalization 36

Split screen, navigation 25

Spoken instructions, navigation 19

State/province, selecting for navigation 7

Station, AM/FM 38

Station, renaming 39

Stations, stored 45

Station, storing 38

Store, see MINI Connected Store 64

Switching calls, see Calls with multiple parties 52

T

Tasks 57

Telephone 50

Telephone conference, see Calls with multiple parties 52

Telephone, operation 50

Teleservice Battery Guard 63

Teleservice Report 62

Teleservices 61

Text messages, see Short messages 54

Text recognition 58

Tone 36

Traffic bulletins, navigation 27

Treble, sound settings 36

Trip, destination guidance with intermediate destinations 12

U

Update, navigation map 31

USB storage device 46

V

Vehicle apps 64

Version of the navigation data 24, 31

Voice command response, smartphone 54

Voice notes 58

Volume equalization 36

Y

Your dealer's service center 63

01405A02CF8 ue



California Proposition 65 Warning

For vehicles sold in California:

California Proposition 65 Warning



WARNING

Operating, servicing and maintaining a passenger vehicle or off-highway motor vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65Warnings.ca.gov/passenger-vehicle.

01405A02CF8 ue

